

# ***Tricks of the Trade***

[www.tintartsigns.com](http://www.tintartsigns.com)

**\*NOTE** - Line up to srt angled hood sides  
Install wet application squeegee down.



Customer Support  
Email: [support@elitelimit.com](mailto:support@elitelimit.com)

Digital Image © Copyright 2008 - [www.tintartsigns.com](http://www.tintartsigns.com)