

Tricks of the Trade

www.tintartsigns.com



***NOTE** - Line up to horizontal body bend line . Install wet application squeegee down flat body then go up to top curve.



Customer Support
Email: support@elitelimit.com

Digital Image © Copyright 2008 - www.tintartsigns.com